


BT209

Bioreaction Engineering

22/03/2023


Autocatalytic reaction and reactor





When a material reacts away ($A \rightarrow R$) by any n^{th} order rate ($n > 0$) in a batch reactor,

- its rate of disappearance is rapid at the start when the concentration of reactant is high.
- This rate then slows progressively as reactant is consumed.

Autocatalytic reaction




- The rate at the start is low because little product is present;
- it increases to a maximum as product is formed
- then drops again to a low value as reactant is consumed.



PFR Vs CSTR for autocatalytic reaction

For any particular rate-concentration curve a comparison of areas in Fig. shows which reactor is superior (which requires a smaller volume) for a given job.


1. At low conversion the mixed reactor is superior to the plug flow reactor.
2. At high enough conversions the plug flow reactor is superior.



➤ These findings differ from ordinary n th-order reactions ($n > 0$) where the plug flow reactor is always more efficient than the mixed flow reactor.


Optimum Recycle Operations

- ❑ In addition, we should note that a plug flow reactor will not operate at all with a feed of pure reactant. In such a situation the feed must be continually primed with product, an ideal opportunity for using a recycle reactor.
- ❑ Using optimization problems we can find the optimum recycle ratio which gives the minimum reactor volume or minimum space time



$$R = \frac{\text{volume of fluid returned to the reactor entrance}}{\text{volume leaving the system}}$$

Cont.



$$\frac{V}{F_{A0}} = \frac{\tau}{C_{A0}} = (R + 1) \int_{\left(\frac{R}{R+1}\right) x_{Af}}^{x_{Af}} \frac{dX_A}{-r_A}$$

✓ The optimum recycle ratio is found by differentiating Eq. with respect to R and setting to zero, thus

$$\frac{d(\tau/C_{A0})}{dR} = 0$$

$$\frac{d(\tau/C_{A0})}{dR} = 0$$

Cont.

$$\frac{d(\tau/C_{A0})}{dR} = 0 \quad \text{for} \quad \frac{V}{F_{A0}} = \frac{\tau}{C_{A0}} = (R+1) \int_{X_{Ai}}^{X_{Af}} \left(\frac{R}{R+1} \right) \frac{dX_A}{-r_A}$$

$$F(R) = \int_{a(R)}^{b(R)} f(x, R) dx$$

$$\frac{dF}{dR} = \int_{a(R)}^{b(R)} \frac{\partial f(x, R)}{\partial R} dx + f(b, R) \frac{db}{dR} - f(a, R) \frac{da}{dR}$$

$$\frac{d(\tau/C_{A0})}{dR} = 0 = \int_{X_{Ai}}^{X_{Af}} \frac{dX_A}{(-r_A)} + 0 - \left. \frac{R+1}{(-r_A)} \right|_{X_{Ai}} \frac{dX_{Ai}}{dR}$$



Cont.

$$X_{Ai} = \left(\frac{R}{R+1} \right) X_{Af} \quad \Rightarrow \quad \frac{dX_{Ai}}{dR} = \frac{X_{Af}}{(R+1)^2}$$

$$\frac{d(\tau/C_{A0})}{dR} = 0 = \int_{X_{Ai}}^{X_{Af}} \frac{dX_A}{(-r_A)} + 0 - \frac{R+1}{(-r_A)} \bigg|_{X_{Ai}} \frac{dX_{Ai}}{dR}$$

$$\frac{1}{-r_A} \bigg|_{X_{Ai}} = \frac{\int_{X_{Ai}}^{X_{Af}} \frac{dX_A}{-r_A}}{(X_{Af} - X_{Ai})}$$




✓ In words, the optimum recycle ratio introduces to the reactor a feed whose $1/(-r_A)$ value (KL in Fig.) equals the average $1/(-r_A)$ value in the reactor as a whole (PQ in Fig.).



Reactor combination for autocatalytic reaction without recycle

❑ For autocatalytic reactions

- In general, for a rate-concentration curve as shown in Fig one should always **try to reach point M in one step (using mixed flow in a single reactor)**, **then follow with plug flow or as close to plug flow as possible**. This procedure is shown as the shaded area in Fig.



Occurrence of Autocatalytic Reactions

- The most important examples of autocatalytic reactions are the broad class of fermentation reactions which result from the reaction of microorganism on an organic feed.
- When they can be treated as single reactions, the methods of this chapter can be applied directly.

S+ Cell → More cell